End Suction Centrifugal Pumps

CSPEF

INSTALLATION AND OPERATING INSTRUCTIONS



⚠ WARNING

IMPORTANT SAFETY INSTRUCTIONS
Rules for Safe Installation and Operation

1. Read these rules and instructions carefully. Failure to follow them may result in serious injury or property damage.
2. Check local codes before installation. Ensure compliance with all relevant regulations.
3. For maximum safety, connect this product to a grounded circuit equipped with a ground fault interrupter (GFI) device.
4. Have an electrician verify the electrical circuit before installation to ensure proper grounding.
5. Before installing or servicing the pump, disconnect the power source.
6. Verify that the line voltage and frequency match the motor specifications. If the motor supports dual voltages, ensure it is wired correctly for your power supply.
7. Protect the pump and piping system from freezing temperatures. Failure to do so may cause severe damage and void the warranty.
8. Avoid system pressures exceeding 1.5 times the operating point specified in the pump performance curve.
9. Do not run the pump dry, as this can damage the pump seal.