Pearl

Stainless Steel Submersible Pumps

# 10PWS800G



| POS. | PARTS NAME |
|---|---|
| 1 | DISCHARGE |
| 2 | LOWER VALVE SEAT RETAINER |
| 4 | VALVE CONE |
| 5 | UPPER VALVE SEAT RETAINER |
| 11 | TOP DIFFUSER |
| 12 | MIDDLE DIFFUSER |
| 18 | IMPELLER |
| 19 | RING OF IMPELLER |
| 21 | SPLIT CONE |
| 22 | SPLIT CONE NUT |
| 26 | SPACING WASHER FOR STOP RING |
| 34 | STRAINER |
| 35 | LOCK FOR STRAINER |
| 36 | SUCTION INTERCONNECTOR |
| 37 | PUMP SHAFT |
| 44 | COUPLING |
| 52 | CABLE GUARD |
| 86 | VALVE SEAT |
| 87 | NECK RING |
| 88 | NUT |
| 89 | BEARING |
| 90 | BEARING |
| 91 | SCREW |
| 92 | KEY |
| 93 | O-RING |
| 94 | O-RING |
| 95 | SPRING |
| 96 | SCREW |
| 97 | SCREW |
| 98 | SPRING WASHER |

